BUILDING AND NEIGHBORHOOD SERVICES

Gary Luffman Director



Dr. Ken Moore Mayor

Eric S. Stuckey City Administrator

HISTORIC
FRANKLIN
TENNESSEE

Basic Procedure (Meadowgreen Sewer Area) for installing a Grinder Pump System (Residential)

	The make/model/type of pump has to be an approved type. Currently, there is one type of	pump
	by E-One Sewer Systems that is approved: the DH071. This is sold by WASCON in	
	Livingston, TN. An interior alarm kit is required.	
	Pay the connection fees at Franklin City Hall Utility Billing. Notify the Utility Billing	
	Department that a grinder pump is to be installed and sign a sewer service agreement and a pressurized sewer agreement.	
	Obtain a Plumbing permit from City of Franklin Building and Neighborhood Services. Bri plot plan with the installation location of the grinder pump marked. The pump location will to be sited so that any odors from the grinder pump will not be a nuisance to adjacent proper	l need
	or to the primary structure.	
	The State Electrical permit should be obtained at the County Admin. Complex on West Ma	in St.
	Complete all electrical inspections and corrections before calling for Plumbing inspections the City.	from
	Call for a Plumbing inspection (Sewer line) before covering the pump and sewer lines.	
	For existing houses with septic systems, the septic tank will have to be abandoned per Cour	nty
	Sewage Disposal Management guidelines. Obtain a 'Technical Assistance' permit and call an inspection to witness the abandonment.	for
	Point of contact at City of Franklin: Chris Bridgewater 550-6633 or	
	chris.bridgewater@franklintn.gov .	
We	ebsite links:	
•	City of Franklin www.franklintn.gov	
•	Franklin Municipal Code Look under the 'Your Government' menu on the Franklin websi	te

• Wmsn. County Sewage Disposal

• E/One Sewer Systems

WASCON

www.williamsoncounty-tn.gov

www.eone.com/sewer_systems/intro/index.htm

www.wasconinc.com

-revised 03.21.11

^{*} Grinder pump installation is regulated by Franklin Municipal Code, the 2009 International Residential Code, and the manufacturer's installation instructions.